

List of Required Parameters for Private Well Testing

	Total Coliform	*E.coli	Nitrate	Iron	Manganese	pH	VOCs	Lead	Arsenic	Mercury	Gross Alpha Particle Activity	Uranium	1,2,3-Trichloropropane	EthyleneDibromide	1,2-Dibromo- 3-chloropropane	Perfluorononanoic acid (PFNA), Perfluorooctanoic acid (PFOA), and Perfluorooctanesulfonic acid (PFOS)
Atlantic	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Bergen	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Burlington	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Camden	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Cape May	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Cumberland	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Essex	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Gloucester	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Hudson	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Hunterdon	X	X	X	X	X	X	X	X	X		x	X	X	X	X	x
Mercer	X	X	X	X	X	X	X	X	X		x	X	X	X	X	x
Middlesex	X	X	X	X	X	X	X	X	X		x	X	X	X	X	x
Monmouth	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Morris	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Ocean	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Passaic	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Salem	X	X	X	X	X	X	X	X	X	X	x		X	X	X	x
Somerset	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Sussex	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Union	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x
Warren	X	X	X	X	X	X	X	X	X		X	X	X	X	X	x

*E. Coli testing is required only if a sample tests positive for total coliform. See N.J.A.C. 7:9E-2.1(a)2.