



State of New Jersey

DEPARTMENT OF ENVIRONMENTAL PROTECTION

401-02B

Bureau of Nonpoint Pollution Control

Division of Water Quality

Post Office Box 420

Trenton, New Jersey 08625-0420

609-633-7021 Fax: 609-777-0432

http://www.state.nj.us/dep/dwq/bnpc_home.htm

August 31, 2011

CHRIS CHRISTIE
Governor

KIM GUADAGNO
Lt. Governor

BOB MARTIN
Commissioner

Dino Pezzimenti
Environment 21, LLC
8713 Read Road, PO Box 55
East Pembroke, NY 14056-0055

Re: MTD Laboratory Test Certification for the V2B1 by Environment 21, LLC

Effective Date: September 1, 2011
Expiration Date: September 1, 2013
TSS Removal Rate: 50%

Dear Mr. Pezzimenti:

The Stormwater Management Rules at N.J.A.C. 7:8 allow the use of manufactured treatment devices (MTDs) for compliance with the design and performance standards provided that the pollutant removal rates have been verified by New Jersey Corporation for Advanced Technology, NJCAT, and certified by the New Jersey Department of Environmental Protection (NJDEP).

The certification process was revised through the "Transition for Manufactured Treatment Devices," dated July 15, 2011. NJDEP has determined that V2B1 by Environmental 21, LLC is consistent with the criteria under *A. Manufactured Treatment Devices with Interim Certifications*. Therefore, **NJDEP certifies the use of the V2B1 by Environmental 21, LLC with a 50% TSS removal rate, provided that the project design is consistent with the following conditions:**

1. The model selected for the project design must be sized in accordance with Table 1 and based on the peak flow of the New Jersey Water Quality Design Storm as specified in N.J.A.C. 7:8-5.
2. The V2B1 can only be used off-line. Any flow above the New Jersey Water Quality Design Storm must utilize an external bypass around the system.

3. A hydrodynamic separator, such as the V2B1, cannot be used in series with another hydrodynamic separator to achieve an enhanced removal rate for total suspended solids (TSS) removal under N.J.A.C. 7:8-5.5.
4. The maintenance plan for the sites using this device shall incorporate at a minimum, the maintenance requirements for the V2B1, attached.

Table 1


V2B1® Model Number^a	M1 Diameter (ft)	M2 Diameter (ft)	Minimum Depth Below Invert (ft)	Treatment Rate (cfs)	Maximum Inlet Pipe Diameter (in)
2	4	4	3.5	0.51	12
3	4	5	3.5	0.66	16
4	5	5	5.5	0.80	21
6	6	5	4.5	0.98	24
7	6	6	4.5	1.15	24
8	7	6	4.5	1.36	30
9	7	5	4.5	1.18	30
10	8	5	4.5	1.42	36
11	8	6	4.5	1.60	36
12	8	7	4.5	1.81	36
13	8	8	5.0	2.05	36
14	10	5	5.0	2.00	42
15	10	6	5.0	2.18	42
16	10	7	5.0	2.38	42
17	10	8	5.0	2.62	42
18	10	10	5.5	3.20	42
19	12	5	5.0	2.70	48
20	12	6	5.0	2.88	48
21	12	7	5.5	3.09	48
22	12	10	5.5	3.90	48
25	12	8	5.5	3.33	48
50	16	10	6.0	5.70	72
60	20	10	6.0	8.00	80

Note: ^a Above models are based on standard precast product availability. System design allows for flows higher than the treatment rate to be bypassed. Custom designs may be provided for cast-in-place applications or alternative precast sizes.

In addition to the attached, any project with a Stormwater BMP subject to the Stormwater Management Rules, N.J.A.C. 7:8, must include a detailed maintenance plan. The detailed maintenance plan must include all of the items identified in Stormwater Management Rules, N.J.A.C. 7:8-5.8. Such items include, but are not limited to, the list of inspection and maintenance equipment and tools, specific corrective and preventative maintenance tasks, indication of problems in the system, and training of maintenance personnel. Additional information can be found in Chapter 8: Maintenance of the New Jersey Stormwater Best Management Manual.

NJDEP anticipates proposing further adjustments to this process through the readoption of the Stormwater Management Rules. Additional information regarding the implementation of the Stormwater Management Rules N.J.A.C. 7:8 are available at www.njstormwater.org. If you have any questions regarding the above information, please contact Ms. Sandra Blick of my office at (609) 633-7021.

Sincerely,

A handwritten signature in black ink, appearing to read 'Ed Frankel', written in a cursive style.

Ed Frankel, P.P., Acting Bureau Chief
Bureau of Nonpoint Pollution Control

C: Richard S. Magee, NJCAT
Chron file

V2B1® SYSTEM MAINTENANCE

1.0 REQUIRED MAINTENANCE FREQUENCY

- 1.1 The required maintenance practice for the V2B1® System is to initially plan on quarterly inspections and an annual pump-out. After experience is gained, the schedule is more accurately determined.
- 1.2 The maintenance interval may be calculated using the following equation:

Estimated Maintenance Interval in Years =

$$\frac{(50\% \text{ of the V2B1 Maximum Sediment Storage Volume})}{(3.366) (\text{Maximum Treatment Flow Rate}) (\text{TSS Removal Efficiency})}$$

This calculation was completed for the current V2B1 models and is included in Attachment A "V2B1 MODEL SIZES WITH DIMENSIONS AND COMPUTED MAINTENANCE INTERVALS" of this document.

- 1.3 It is required that the V2B1® System should be pumped out when the sediment depth in the first structure is at 50% of the design sediment storage depth, which is, minimally, every six months. Refer to the project design package for the storage depth.
- 1.4 Oil sheen and floating debris are retained in the second chamber of the V2B1® System. Annual accumulation of floatables is estimated at less than 0.50 inches but is site dependent.

2.0 CONDITIONS THAT CAUSE THE NEED FOR MAINTENANCE

- 2.1 The most common cause of poor performance of the V2B1® System is lack of maintenance. The V2B1® System removes pollution from the environment. If this pollution is not routinely removed, the effectiveness of the V2B1® System could be compromised. The following are things that trigger the need for maintenance and the consequences of not completing the maintenance.
 - 2.1.1 Sediment build-up in the chambers. As the sediment level increases past the recommended maintenance interval less sediment would be removed from the runoff. Additionally a large

storm could cause entrainment of some of the sediment that was already captured.

- 2.1.2 Excess floatables in the chambers. Similar to sediment build-up floatables (oil and litter) build-up and risk downstream pollution
- 2.1.3 Obstructed piping/baffles due to improper maintenance and removal of floating debris. If the piping or baffles become obstructed flooding may occur upstream of the V2B1® System.
- 2.1.4 As with most buried structures, the vented covers could be moved out of position during extreme flooding conditions.
- 2.2 In addition to V2B1® System internal inspections, frequent site inspections should be conducted. These frequent site inspections are recommended as visual only and do not require tools or equipment or removal of the vented covers. Things to look for during these inspections are flooding at catch basins upstream of the V2B1® System, unexpected loss of outlet flow, out of place vented covers and downstream pollution (oil sheen, litter, etc.).

3.0 ACCESS POINTS AND REQUIRED INSPECTION

- 3.1 Maintenance access is through cast iron frames with vented covers that are provided, two per structure, in the V2B1® System roof.
- 3.2 Remove one of the cast iron vented covers of the V2B1® System. The floatables observation and measurement can be obtained from all access points.
- 3.3 Illuminate the water surface in the first stage of the V2B1® System while gently stirring the floatables to estimate the depth. Obtain a sample of the floatables, water, or sediment, if required to determine disposal. The depth of the oil sheen and floating debris will typically be less than one inch and can be skimmed from the surface prior to the pump-out of the sediment. Organic debris that has become waterlogged and settled to the floor is expected to be present in relatively small quantities that will be removed during the pump out of the mineral sediment.
- 3.4 Inspect all surfaces, which can be seen, of the V2B1® System for wear (e.g., cracking, spalling, etc.). Also, examine the inlet and elbow pipes for

wear, blockage, and damage (cracks, etc.). Report signs of degradation to the proper authorities (i.e., owner, municipality, etc.) as required.

- 3.5 Lower the measuring rod into the V2B1® System until a slight resistance to movement occurs; the rod is now at the top of the sediment pile. Obtain a measurement by sighting the rod measuring increments to a point on the cover frame. This is measurement A.
- 3.6 Twist the measuring rod into the sediment pile until the measuring rod is on the floor (verify the expected level using the project submittal drawings). Obtain a measurement by sighting the rod increments to the same point on the access frame as was used in step 3.5. This is measurement B.
- 3.7 Refer to the Environment 21 system specific design package for the design sediment storage depth. This is measurement C.
- 3.8 Plug the numbers obtained from the previous three steps into the following equation:

$$(B - A)/C.$$
 Multiply the answer by 100 to obtain the percent full sediment depth of the V2B1® System.
- 3.9 Complete Steps 3.2 through 3.8 for all of the chambers of the V2B1® System.
- 3.10 Contact the following for approval and notification of the intent to pump out the V2B1® System:
 - 3.10.1 Obtain permission from the Owner to pump out the contents of the V2B1® System.
 - 3.10.2 Verify the disposal requirements with the local regulatory agency
- 3.11 Obtain a standard truck-mounted sewer and catch basin cleaner with positive displacement rotary lobe vacuum pumps or other acceptable pump-out equipment.
- 3.12 Using the pump-out equipment, remove the floatables and hydrocarbons from the V2B1® System. Segregate this waste from the sediment and water as required.

- 3.13 Using the pump-out equipment, remove the standing water and sediment from the V2B1® System. Segregate this waste from the hydrocarbons and floatables as required.
- 3.14 Locate and use a water supply to wash down the interior surface of the V2B1® System and remove the remaining waste from the bottom of the structure.
- 3.15 Repeat steps 3.12 through 3.14 for all of the chambers of the V2B1® System.
- 3.16 Using a flood light inspect all surfaces, which can be seen, of the V2B1® System for wear (e.g., cracking, spalling, etc.). Also examine the inlet and elbow pipes for wear, blockage, and damage (cracks, etc.). Report signs of degradation to the proper authorities (i.e., owner, municipality, etc.) as required.
- 3.17 Refill the V2B1® System, with clean water, to the inlet/outlet pipe invert elevation.
- 3.18 Properly dispose of the waste removed from V2B1® System
- 3.19 Verify that no personnel, tools or equipment are in the V2B1® System.
- 3.20 Inspect the cast iron access frames and covers for damage (e.g., cracks, excessive wear, etc.).
- 3.21 Clear the cast iron access frames of any extraneous material and carefully replace the cast iron vented covers using proper lifting and rigging equipment. Verify that the covers are properly seated.
- 3.22 Remove the site set-up (tools, equipment, etc.) and verify the work area has been returned to its pre-work, or better, condition.
- 3.23 Complete an inventory of all tools and equipment used for this work, accounting for lost, damaged, or stolen tools or equipment.
- 3.24 Maintenance is a very important aspect in keeping the V2B1® System performance up to par. Attachment B "V2B1® SYSTEM MAINTENANCE DATA SHEET" is provided and should be used to document the maintenance performed on the V2B1® System.

- 3.25 Provide a copy of the "V2B1® SYSTEM MAINTENANCE DATA SHEET" to the owner, required government agencies, and Environment 21, LLC (P.O. Box 55, East Pembroke, NY 14056-1055).

4.0 REQUIRED TRAINING

- 4.1 Safety is a priority and the most stringent of regulations (local, OSHA, etc.) should be followed while performing maintenance on V2B1® System.
- 4.2 An advantage of the design of the V2B1® System is such that all of the maintenance may be completed without entry. In the remote chance that entry into the V2B1® System is required refer to regulations (local, OSHA, etc.) for requirements and definitions.
- 4.3 A running inventory of all tools and equipment used for completion of this procedure should be maintained while performing maintenance on the V2B1® System.
- 4.4 The V2B1® System has cast iron access frames with vented covers, which provide access to all of the V2B1® System. The openings are normally at ground level so the work area should be staged properly with safeguards to prevent anyone or anything from inadvertently falling through an opening in the V2B1® System.
- 4.5 After maintenance has been completed on the V2B1® System, the cast iron vented covers should be set securely in place, all materials and equipment should be removed, and the area should be cleared of slip and trip hazards.
- 4.6 Other than this procedure and the specific project data there is currently no other training media (e.g., videos). This document along with the project specific data captures the maintenance procedure and training. Maintenance questions can be answered by calling Environment 21 at 800-809-2801.

5.0 REQUIRED EQUIPMENT

- 5.1 Some of the recommended tools are a flood light, proper lifting and rigging equipment, and an unbending measuring rod (increments in inches

marked on the rod) that will reach the floor of the V2B1® System and still extend a minimum of 2' above the cast iron access frame.


- 5.2 Environment 21, LLC should be contacted if any repairs or replacement of parts are required so the correct repairs and parts may be obtained.

ATTACHMENT A

V2B1 MODEL SIZES WITH DIMENSIONS AND COMPUTED MAINTENANCE INTERVALS


V2B1 MODEL	M1 DIA. (ft.)	M2 DIA. (ft.)	M1 INLET DIA. RANGE (in.)	M1 OUTLET DIA. RANGE (in.)	M2 INLET DIA. RANGE (in.)	M2 OUTLET DIA. RANGE (in.)	BYPASS RANGE (in.)	MIN. SUMP DEPTH (ft.)	MTFR (ft ³ /s)	TSS REM. EFF. (%)	MIN. STORAGE VOLUME (ft ³)	COMPUTED MAINT. INTERVAL (years)
2	4	4	8 - 12	8 - 24	8 - 24	8 - 24	4 - 10	3.5	0.51	50%	18.85	11.0
3	4	5	10 - 16	10 - 24	10 - 24	10 - 24	4 - 10	3.5	0.66	50%	22.38	10.1
4(1)	5	5	12 - 21	12 - 36	12 - 36	12 - 36	6 - 12	5.5	0.80	50%	29.45	10.9
6	6	5	12 - 24	12 - 36	12 - 36	12 - 36	6 - 12	4.5	0.98	50%	38.09	11.5
7	6	6	12 - 24	12 - 36	12 - 36	12 - 36	6 - 15	4.5	1.15	50%	42.41	11.0
8	7	6	15 - 30	15 - 36	15 - 36	15 - 36	6 - 15	4.5	1.36	50%	52.62	11.5
9	7	5	15 - 30	15 - 36	15 - 36	15 - 36	6 - 12	4.5	1.18	50%	48.30	12.2
10	8	5	15 - 36	15 - 36	15 - 36	15 - 36	6 - 12	4.5	1.42	50%	60.08	12.6
11	8	6	15 - 36	15 - 36	15 - 36	15 - 36	6 - 15	4.5	1.60	50%	64.40	12.0
12	8	7	15 - 36	15 - 42	15 - 42	15 - 42	6 - 18	4.5	1.81	50%	69.51	11.4
13	8	8	15 - 36	15 - 48	15 - 48	15 - 48	6 - 18	5.0	2.05	50%	75.40	10.9
14	10	5	18 - 42	18 - 36	18 - 36	18 - 36	6 - 12	5.0	2.00	50%	88.36	13.1
15	10	6	18 - 42	18 - 36	18 - 36	18 - 36	6 - 15	5.0	2.18	50%	92.68	12.6
16	10	7	18 - 42	18 - 42	18 - 42	18 - 42	6 - 18	5.0	2.38	50%	97.78	12.2
17	10	8	18 - 42	18 - 48	18 - 48	18 - 48	8 - 24	5.0	2.62	50%	103.67	11.8
18	10	10	18 - 48	18 - 60	18 - 60	18 - 60	8 - 36	5.5	3.20	50%	117.81	10.9
19	12	5	21 - 48	21 - 36	21 - 36	21 - 36	6 - 12	5.0	2.70	50%	122.92	13.5
20	12	6	21 - 48	21 - 36	21 - 36	21 - 36	6 - 15	5.0	2.88	50%	127.23	13.1
21	12	7	21 - 48	21 - 36	21 - 36	21 - 36	6 - 18	5.5	3.09	50%	132.34	12.7
22	12	10	21 - 48	21 - 48	21 - 48	21 - 48	10 - 36	5.5	3.90	50%	152.37	11.6
25	12	8	21 - 48	21 - 48	21 - 48	21 - 48	6 - 15	5.5	3.33	50%	138.23	12.3
50	16	10	24 - 72	24 - 60	24 - 60	24 - 60	10 - 36	6.0	5.70	50%	240.33	12.5
60	20	10	30 - 80	30 - 60	30 - 60	30 - 60	10 - 36	6.0	8.00	50%	353.43	13.1

(1) This model was used for testing.



Environment
Global Stormwater Solutions

P.O. Box 55 | East Pembroke | NY 14056
Phone: 1-800-809-2801 | Fax: 1-585-815-4701
www.v2b1.com | 609.627.1200



V2B1
Technology That Separates

ATTACHMENT B

V2B1 SYSTEM MAINTENANCE DATA SHEET

STRUCTURE NO.: _____

OWNER: _____

ADDRESS: _____

V2B1 MODEL _____

DATE INSTALLED:				MUNICIPALITY:									
DATE	SEDIMENT PILE DEPTH *			OIL SHEEN YES/NO *			FLOATABLE DEPTH *			PUMPOUT REQ. YES/NO	SAMPLED YES/NO	SAMPLE RESULTS	
	1st	2nd	3rd	1st	2nd	3rd	1st	2nd	3rd				

PUMPOUT DATA (IF APPLICABLE)											
DATE	SEDIMENT VOLUME REMOVED			FLOATABLES VOLUME REMOVED			DISPOSAL INFORMATION				
							SEDIMENT		FLOATABLE:		



environmenta
Global Stormwater Solutions

P.O. Box 55 | East Pembroke | NY 14056
Phone: 1-800-808-2801 | Fax: 1-585-815-4701
www.env21.com | env21@env21.com

ENV21
Technology That Separates

**ATTACHMENT B
PRIOR TO START OF WORK**

OWNER NOTIFIED AS REQUIRED. ☐ ☐

LOCAL AGENCIES NOTIFIED AS REQUIRED. ☐ ☐

INSPECTION

PIPING

	YES	NO
ANY VISIBLE CRACKS/DAMAGE	<input type="checkbox"/>	<input type="checkbox"/>
ANY VISIBLE DISPLACEMENT/LEAKS	<input type="checkbox"/>	<input type="checkbox"/>
ANY VISIBLE OBSTRUCTIONS	<input type="checkbox"/>	<input type="checkbox"/>

STRUCTURE

	YES	NO
ANY VISIBLE CRACKS/SPALLING/DAMAGE	<input type="checkbox"/>	<input type="checkbox"/>
ANY VISIBLE LEAKS	<input type="checkbox"/>	<input type="checkbox"/>
ANY VISIBLE SURFACE WEAR	<input type="checkbox"/>	<input type="checkbox"/>

1st, 2nd, and 3rd refer to the three chambers of the V2B1.



environment
Global Stormwater Solutions

P.O. Box 55 | East Pembroke | NY 14056
PHONE: 1-800-809-2301 | FAX: 1-585-615-4701
www.enr21.com | enr21@enr21.com

ENR21
Technology That Separates

ATTACHMENT B

VENTED COVERS/FRAMES

YES	NO
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>

ANY VISIBLE CRACKS/DAMAGE

ANY VISIBLE SEAT SURFACE OBSTRUCTIONS

WERE COVERS PROPERLY SEATED AS FOUND

AFTER WORK COMPLETION

ALL CAST IRON COVERS HAVE BEEN PROPERLY REPLACED.

NO HAZARDOUS CONDITIONS EXIST AS A RESULT OF THE MAINTENANCE WORK.

ALL PPE, TOOLS, AND EQUIPMENT HAVE BEEN INVENTORIED AND REMOVED FROM THE SITE.

THE WORK AREA HAS BEEN RETURNED TO A SAFE PRE-WORK CONDITION.

ALL NOTIFICATIONS HAVE BEEN MADE, AS REQUIRED, THAT THE WORK IS COMPLETED.

CORRECTIVE ACTIONS TAKEN:

DATE: _____ **SIGNATURE:** _____

^{1st}, ^{2nd}, and ^{3rd} refer to the three chambers of the V2B1.



State of New Jersey

DEPARTMENT OF ENVIRONMENTAL PROTECTION
Bureau of Nonpoint Pollution Control
Division of Water Quality
Post Office Box 029
Trenton, New Jersey 08625-029
609-633-7021 Fax: 609-984-2147
http://www.state.nj.us/dep/dwq/bnpc_home.htm

JON S. CORZINE
Governor

MARK N. MAURIELLO
Acting Commissioner

December 2, 2009

Dino Pezzimenti
Environment 21, LLC
8713 Read Road, PO Box 55
East Pembroke, NY 14056-0055

Re: Table 1 for Conditional Interim Certification for the V2B1[®] Stormwater Treatment System by
Environment 21, LLC

Expiration Date: May 15, 2011
TSS Removal Rate: 50%

Dear Mr. Pezzimenti:

This is in reference to the conditional interim certification cited above. Due to a typographical error, Table 1 was not indicated. Table 1 is attached.

Please note that this letter does not modify any of the conditions listed on the November 13, 2009 Conditional Interim Certification.

Please attach this letter to your copy of the November 13, 2009 Conditional Interim Certification. If you have any questions regarding the above information, please contact Sandra Blick at (609) 633-7021.

Sincerely,

Barry Chalofsky, P.P., Chief
Bureau of Nonpoint Pollution Control

c: Tom Micai, NJDEP
Mary Beth Brenner, NJDEP
Rhea Weinberg Brekke, NJCAT
Elizabeth Dragon, NJDEP

Table 1 V2B1 Treatment Rates (Based on NJDEP PSD)

V2B1® Model Number	M1 Diameter (ft)	M2 Diameter (ft)	Minimum Depth Below Invert (ft)	Treatment Rate (cfs)	Maximum Inlet Pipe Diameter (in)
2	4	4	3.5	0.51	12
3	4	5	3.5	0.66	16
4	5	5	5.5	0.80	21
6	6	5	4.5	0.98	24
7	6	6	4.5	1.15	24
8	7	6	4.5	1.36	30
9	7	5	4.5	1.18	30
10	8	5	4.5	1.42	36
11	8	6	4.5	1.60	36
12	8	7	4.5	1.81	36
13	8	8	5.0	2.05	36
14	10	5	5.0	2.00	42
15	10	6	5.0	2.18	42
16	10	7	5.0	2.38	42
17	10	8	5.0	2.62	42
18	10	10	5.5	3.20	42
19	12	5	5.0	2.70	48
20	12	6	5.0	2.88	48
21	12	7	5.5	3.09	48
22	12	10	5.5	3.90	48
25	12	8	5.5	3.33	48
50	16	10	6.0	5.70	72
60	20	10	6.0	8.00	80



State of New Jersey

DEPARTMENT OF ENVIRONMENTAL PROTECTION

Bureau of Nonpoint Pollution Control

Division of Water Quality

Post Office Box 029

Trenton, New Jersey 08625-029

609-633-7021 Fax: 609-984-2147

http://www.state.nj.us/dep/dwq/bnpc_home.htm

JON S. CORZINE
Governor

MARK N. MAURIELLO
Acting Commissioner

November 13, 2009

Dino Pezzimenti
Environment 21, LLC
8713 Read Road, PO Box 55
East Pembroke, NY 14056-0055

Re: Conditional Interim Certification for the V2B1[®] Stormwater Treatment System by Environment 21, LLC

Expiration Date: May 15, 2011

TSS Removal Rate: 50%

Dear Mr. Pezzimenti:

The Stormwater Management Rules under N.J.A.C. 7:8-5.5(b) and 5.7(c) allow the use of manufactured treatment devices (MTDs) for compliance with the design and performance standards at N.J.A.C. 7:8-5 if the pollutant removal rates have been verified by New Jersey Corporation for Advanced Technology (NJCAT) and have been certified by the New Jersey Department of Environmental Protection (NJDEP).

The certification process has been revised. The revised process places MTDs into five categories. The V2B1[®] Stormwater Treatment System by Environment 21, LLC has been qualified for Category III, MTDs with NJCAT Verification issued as of May 15, 2009.

The V2B1[®] Stormwater Treatment System, shown in figure 1, is comprised of a hydrodynamic treatment system for stormwater runoff in which two manholes are used to remove sediments from runoff.

The NJDEP received the submitted data demonstrating the above approved TSS Removal Rate, a maintenance plan required under Category III, and a signed statement indicating that the 2009 NJDEP Testing Protocols as amended and supplemented (Hydrodynamic, Filter, or Field requirements in accordance with NJ Amendments of TARP) are unincorporated into the maintenance plan.




Figure 1 V2B1[®] Stormwater Treatment System

Based on to the verification and the Department's review, the Department acknowledges that the requirements for this category are met; therefore, grants interim certification with an expiration date of May 15, 2011. The NJDEP certifies the use of the V2B1[®] Stormwater Treatment System by Environment 21, LLC at a TSS removal rate of 50%, subject to the following conditions:


1. The V2B1[®] Stormwater Treatment System is designed according to the NJ Water Quality Design Storm in N.J.A.C. 7:8-5.5.
2. The various models and associated water quality flow capacities shall be sized for the peak flow of the New Jersey water quality design storm per N.J.A.C. 7:8-5, as shown in Table 1.
3. The V2B1[®] Stormwater Treatment System is certified as an off-line system only. Any flow above the New Jersey water quality design storm must be bypassed around the system.
4. A hydrodynamic separator, such as V2B1[®] Stormwater Treatment System, cannot be used in series with another settling device to achieve an enhanced removal rate for total suspended solids (TSS) removal under N.J.A.C. 7:8-5.5.
5. The maintenance plan for sites using this device shall incorporate, at a minimum, the maintenance requirements for the V2B1[®] Stormwater Treatment System shown in the attachment entitled "V2B1[®] SYSTEM MAINTENANCE".

In addition to the attached, the detailed maintenance plan must include all of the items identified in Chapter 8: Maintenance of the New Jersey Stormwater Best Management Manual. Such items include, but are not limited to, the list of inspection and maintenance equipment and tools, specific corrective and preventative maintenance tasks, indication of problems in the system, and training of maintenance personnel. Additional operation and maintenance information

associated with this manufactured treatment device is available from the vendor to assist in the development of a complete maintenance plan.

The Department anticipates proposing further adjustments to this process through the readoption of the Stormwater Management Rules. Additional information regarding the implementation of the Stormwater Management Rules N.J.A.C. 7:8 are available at www.njstormwater.org. If you have any questions regarding the above information, please contact Ms. Sandra Blick of my office at (609) 633-7021.

Sincerely,

A handwritten signature in dark ink, appearing to read "B. CR", written over a horizontal line.

Barry Chalofsky, P.P., Chief
Bureau of Nonpoint Pollution Control

c: Tom Micai, NJDEP
Mary Beth Brenner, NJDEP
Rhea Weinberg Brekke, NJCAT
Elizabeth Dragon, NJDEP

V2B1® SYSTEM MAINTENANCE

1.0 REQUIRED MAINTENANCE FREQUENCY

- 1.1 The required maintenance practice for the V2B1® System is to initially plan on quarterly inspections and an annual pump-out. After experience is gained, the schedule is more accurately determined.
- 1.2 The maintenance interval may be calculated using the following equation:

Estimated Maintenance Interval in Years =

$$\frac{(50\% \text{ of the V2B1 Maximum Sediment Storage Volume})}{(3.366) (\text{Maximum Treatment Flow Rate}) (\text{TSS Removal Efficiency})}$$

This calculation was completed for the current V2B1 models and is included in Attachment A "V2B1 MODEL SIZES WITH DIMENSIONS AND COMPUTED MAINTENANCE INTERVALS" of this document.

- 1.3 It is required that the V2B1® System should be pumped out when the sediment depth in the first structure is at 50% of the design sediment storage depth, which is, minimally, every six months. Refer to the project design package for the storage depth.
- 1.4 Oil sheen and floating debris are retained in the second chamber of the V2B1® System. Annual accumulation of floatables is estimated at less than 0.50 inches but is site dependent.

2.0 CONDITIONS THAT CAUSE THE NEED FOR MAINTENANCE

- 2.1 The most common cause of poor performance of the V2B1® System is lack of maintenance. The V2B1® System removes pollution from the environment. If this pollution is not routinely removed, the effectiveness of the V2B1® System could be compromised. The following are things that trigger the need for maintenance and the consequences of not completing the maintenance.
 - 2.1.1 Sediment build-up in the chambers. As the sediment level increases past the recommended maintenance interval less sediment would be removed from the runoff. Additionally a large

storm could cause entrainment of some of the sediment that was already captured.

- 2.1.2 Excess floatables in the chambers. Similar to sediment build-up floatables (oil and litter) build-up and risk downstream pollution
- 2.1.3 Obstructed piping/baffles due to improper maintenance and removal of floating debris. If the piping or baffles become obstructed flooding may occur upstream of the V2B1® System.
- 2.1.4 As with most buried structures, the vented covers could be moved out of position during extreme flooding conditions.
- 2.2 In addition to V2B1® System internal inspections, frequent site inspections should be conducted. These frequent site inspections are recommended as visual only and do not require tools or equipment or removal of the vented covers. Things to look for during these inspections are flooding at catch basins upstream of the V2B1® System, unexpected loss of outlet flow, out of place vented covers and downstream pollution (oil sheen, litter, etc.).

3.0 ACCESS POINTS AND REQUIRED INSPECTION

- 3.1 Maintenance access is through cast iron frames with vented covers that are provided, two per structure, in the V2B1® System roof.
- 3.2 Remove one of the cast iron vented covers of the V2B1® System. The floatables observation and measurement can be obtained from all access points.
- 3.3 Illuminate the water surface in the first stage of the V2B1® System while gently stirring the floatables to estimate the depth. Obtain a sample of the floatables, water, or sediment, if required to determine disposal. The depth of the oil sheen and floating debris will typically be less than one inch and can be skimmed from the surface prior to the pump-out of the sediment. Organic debris that has become waterlogged and settled to the floor is expected to be present in relatively small quantities that will be removed during the pump out of the mineral sediment.
- 3.4 Inspect all surfaces, which can be seen, of the V2B1® System for wear (e.g., cracking, spalling, etc.). Also, examine the inlet and elbow pipes for



wear, blockage, and damage (cracks, etc.). Report signs of degradation to the proper authorities (i.e., owner, municipality, etc.) as required.

- 3.5 Lower the measuring rod into the V2B1® System until a slight resistance to movement occurs; the rod is now at the top of the sediment pile. Obtain a measurement by sighting the rod measuring increments to a point on the cover frame. This is measurement A.
- 3.6 Twist the measuring rod into the sediment pile until the measuring rod is on the floor (verify the expected level using the project submittal drawings). Obtain a measurement by sighting the rod increments to the same point on the access frame as was used in step 3.5. This is measurement B.
- 3.7 Refer to the Environment 21 system specific design package for the design sediment storage depth. This is measurement C.
- 3.8 Plug the numbers obtained from the previous three steps into the following equation:

$$(B - A)/C.$$
 Multiply the answer by 100 to obtain the percent full sediment depth of the V2B1® System.
- 3.9 Complete Steps 3.2 through 3.8 for all of the chambers of the V2B1® System.
- 3.10 Contact the following for approval and notification of the intent to pump out the V2B1® System:
 - 3.10.1 Obtain permission from the Owner to pump out the contents of the V2B1® System.
 - 3.10.2 Verify the disposal requirements with the local regulatory agency
- 3.11 Obtain a standard truck-mounted sewer and catch basin cleaner with positive displacement rotary lobe vacuum pumps or other acceptable pump-out equipment.
- 3.12 Using the pump-out equipment, remove the floatables and hydrocarbons from the V2B1® System. Segregate this waste from the sediment and water as required.



- 3.13 Using the pump-out equipment, remove the standing water and sediment from the V2B1® System. Segregate this waste from the hydrocarbons and floatables as required.
- 3.14 Locate and use a water supply to wash down the interior surface of the V2B1® System and remove the remaining waste from the bottom of the structure.
- 3.15 Repeat steps 3.12 through 3.14 for all of the chambers of the V2B1® System.
- 3.16 Using a flood light inspect all surfaces, which can be seen, of the V2B1® System for wear (e.g., cracking, spalling, etc.). Also examine the inlet and elbow pipes for wear, blockage, and damage (cracks, etc.). Report signs of degradation to the proper authorities (i.e., owner, municipality, etc.) as required.
- 3.17 Refill the V2B1® System, with clean water, to the inlet/outlet pipe invert elevation.
- 3.18 Properly dispose of the waste removed from V2B1® System
- 3.19 Verify that no personnel, tools or equipment are in the V2B1® System.
- 3.20 Inspect the cast iron access frames and covers for damage (e.g., cracks, excessive wear, etc.).
- 3.21 Clear the cast iron access frames of any extraneous material and carefully replace the cast iron vented covers using proper lifting and rigging equipment. Verify that the covers are properly seated.
- 3.22 Remove the site set-up (tools, equipment, etc.) and verify the work area has been returned to its pre-work, or better, condition.
- 3.23 Complete an inventory of all tools and equipment used for this work, accounting for lost, damaged, or stolen tools or equipment.
- 3.24 Maintenance is a very important aspect in keeping the V2B1® System performance up to par. Attachment B "V2B1® SYSTEM MAINTENANCE DATA SHEET" is provided and should be used to document the maintenance performed on the V2B1® System.



- 3.25 Provide a copy of the "V2B1® SYSTEM MAINTENANCE DATA SHEET" to the owner, required government agencies, and Environment 21, LLC (P.O. Box 55, East Pembroke, NY 14056-1055).

4.0 REQUIRED TRAINING

- 4.1 Safety is a priority and the most stringent of regulations (local, OSHA, etc.) should be followed while performing maintenance on V2B1® System.
- 4.2 An advantage of the design of the V2B1® System is such that all of the maintenance may be completed without entry. In the remote chance that entry into the V2B1® System is required refer to regulations (local, OSHA, etc.) for requirements and definitions.
- 4.3 A running inventory of all tools and equipment used for completion of this procedure should be maintained while performing maintenance on the V2B1® System.
- 4.4 The V2B1® System has cast iron access frames with vented covers, which provide access to all of the V2B1® System. The openings are normally at ground level so the work area should be staged properly with safeguards to prevent anyone or anything from inadvertently falling through an opening in the V2B1® System.
- 4.5 After maintenance has been completed on the V2B1® System, the cast iron vented covers should be set securely in place, all materials and equipment should be removed, and the area should be cleared of slip and trip hazards.
- 4.6 Other than this procedure and the specific project data there is currently no other training media (e.g., videos). This document along with the project specific data captures the maintenance procedure and training. Maintenance questions can be answered by calling Environment 21 at 800-809-2801.

5.0 REQUIRED EQUIPMENT

- 5.1 Some of the recommended tools are a flood light, proper lifting and rigging equipment, and an unbending measuring rod (increments in inches



environment
Global Stormwater Solutions

P.O. Box 55 | East Pembroke | NY 14056
Phone: 1-800-809-2001 | Fax: 1-585-815-4701
www.env21.com | enveng@env21.com

ENV
Technology That Separates

marked on the rod) that will reach the floor of the V2B1® System and still extend a minimum of 2' above the cast iron access frame.

- 5.2 Environment 21, LLC should be contacted if any repairs or replacement of parts are required so the correct repairs and parts may be obtained.

ATTACHMENT A

V2B1 MODEL SIZES WITH DIMENSIONS AND COMPUTED MAINTENANCE INTERVALS

V2B1 MODEL	M1 DIA. (ft.)	M2 DIA. (ft.)	M1 INLET DIA. RANGE (in.)	M1 OUTLET DIA. RANGE (in.)	M2 INLET DIA. RANGE (in.)	M2 OUTLET DIA. RANGE (in.)	BYPASS RANGE (in.)	MIN. SUMP DEPTH (ft.)	MTFR (ft ³ /s)	TSS REM. EFF. (%)	MIN. STORAGE VOLUME (ft ³)	COMPUTED MAINT. INTERVAL (years)
2	4	4	8 - 12	8 - 24	8 - 24	8 - 24	4 - 10	3.5	0.51	50%	18.85	11.0
3	4	5	10 - 16	10 - 24	10 - 24	10 - 24	4 - 10	3.5	0.66	50%	22.38	10.1
4 ⁽¹⁾	5	5	12 - 21	12 - 36	12 - 36	12 - 36	6 - 12	5.5	0.80	50%	29.45	10.9
6	6	5	12 - 24	12 - 36	12 - 36	12 - 36	6 - 12	4.5	0.98	50%	38.09	11.5
7	6	6	12 - 24	12 - 36	12 - 36	12 - 36	6 - 15	4.5	1.15	50%	42.41	11.0
8	7	6	15 - 30	15 - 36	15 - 36	15 - 36	6 - 15	4.5	1.36	50%	52.62	11.5
9	7	5	15 - 30	15 - 36	15 - 36	15 - 36	6 - 12	4.5	1.18	50%	48.30	12.2
10	8	5	15 - 36	15 - 36	15 - 36	15 - 36	6 - 12	4.5	1.42	50%	60.08	12.6
11	8	6	15 - 36	15 - 36	15 - 36	15 - 36	6 - 15	4.5	1.60	50%	64.40	12.0
12	8	7	15 - 36	15 - 42	15 - 42	15 - 42	6 - 18	4.5	1.81	50%	69.51	11.4
13	8	8	15 - 36	15 - 48	15 - 48	15 - 48	6 - 18	5.0	2.05	50%	75.40	10.9
14	10	5	18 - 42	18 - 36	18 - 36	18 - 36	6 - 12	5.0	2.00	50%	88.36	13.1
15	10	6	18 - 42	18 - 36	18 - 36	18 - 36	6 - 15	5.0	2.18	50%	92.68	12.6
16	10	7	18 - 42	18 - 42	18 - 42	18 - 42	6 - 18	5.0	2.38	50%	97.78	12.2
17	10	8	18 - 42	18 - 48	18 - 48	18 - 48	8 - 24	5.0	2.62	50%	103.67	11.8
18	10	10	18 - 48	18 - 60	18 - 60	18 - 60	8 - 36	5.5	3.20	50%	117.81	10.9
19	12	5	21 - 48	21 - 36	21 - 36	21 - 36	6 - 12	5.0	2.70	50%	122.92	13.5
20	12	6	21 - 48	21 - 36	21 - 36	21 - 36	6 - 15	5.0	2.88	50%	127.23	13.1
21	12	7	21 - 48	21 - 36	21 - 36	21 - 36	6 - 18	5.5	3.09	50%	132.34	12.7
22	12	10	21 - 48	21 - 48	21 - 48	21 - 48	10 - 36	5.5	3.90	50%	152.37	11.6
25	12	8	21 - 48	21 - 48	21 - 48	21 - 48	6 - 15	5.5	3.33	50%	138.23	12.3
50	16	10	24 - 72	24 - 60	24 - 60	24 - 60	10 - 36	6.0	5.70	50%	240.33	12.5
60	20	10	30 - 80	30 - 60	30 - 60	30 - 60	10 - 36	6.0	8.00	50%	353.43	13.1

(1) This model was used for testing.



environment
Global Stormwater Solutions

P.O. Box 55 | East Pembroke | NY 14056
Phone: 1-800-809-2801 | Fax: 1-585-815-4701
www.env21.com | enveng@env21.com

ENV
Technology That Separates

ATTACHMENT B

V2B1 SYSTEM MAINTENANCE DATA SHEET

STRUCTURE NO.: _____

ADDRESS: _____

OWNER: _____

V2B1 MODEL _____

DATE INSTALLED: _____

MUNICIPALITY: _____

DATE	SEDIMENT PILE DEPTH *			OIL SHEEN YES/NO *			FLOATABLE DEPTH *			PUMPOUT REQ. YES/NO	SAMPLED YES/NO	SAMPLE RESULTS
	1st	2nd	3rd	1st	2nd	3rd	1st	2nd	3rd			

PUMPOUT DATA (IF APPLICABLE)

DATE	SEDIMENT VOLUME REMOVED	FLOATABLES VOLUME REMOVED	DISPOSAL INFORMATION	
			SEDIMENT	FLOATABLE:

1st, 2nd, and 3rd refer to the three chambers of the V2B1.



environment
Global Stormwater Solutions

P.O. Box 55 | East Pembroke | NY 14056
Phone: 1-800-809-2801 | Fax: 1-585-815-4701
www.env21.com | enveng@env21.com

ENV
Technology That Separates

**ATTACHMENT B
PRIOR TO START OF WORK**

OWNER NOTIFIED AS REQUIRED.

☐

LOCAL AGENCIES NOTIFIED AS REQUIRED.

☐

INSPECTION

PIPING

YES

NO

ANY VISIBLE CRACKS/DAMAGE

☐☐

ANY VISIBLE DISPLACEMENT/LEAKS

☐☐

ANY VISIBLE OBSTRUCTIONS

☐☐

STRUCTURE

YES

NO

ANY VISIBLE CRACKS/SPALLING/DAMAGE

☐☐

ANY VISIBLE LEAKS

☐☐

ANY VISIBLE SURFACE WEAR

☐☐



environment
Global Stormwater Solutions

P.O. Box 55 | East Pembroke | NY 14056
Phone: 1-800-809-2801 | Fax: 1-585-815-4701
www.env21.com | enveng@env21.com

ENV
Technology That Separates

ATTACHMENT B

VENTED COVERS/FRAMES

YES

NO

ANY VISIBLE CRACKS/DAMAGE

☐☐

ANY VISIBLE SEAT SURFACE OBSTRUCTIONS

☐☐

WERE COVERS PROPERLY SEATED AS FOUND

☐☐

AFTER WORK COMPLETION

ALL CAST IRON COVERS HAVE BEEN PROPERLY REPLACED.

☐☐

NO HAZARDOUS CONDITIONS EXIST AS A RESULT OF THE MAINTENANCE WORK.

☐☐

ALL PPE, TOOLS, AND EQUIPMENT HAVE BEEN INVENTORIED AND REMOVED FROM THE SITE.

☐☐

THE WORK AREA HAS BEEN RETURNED TO A SAFE PRE-WORK CONDITION.

☐☐

ALL NOTIFICATIONS HAVE BEEN MADE, AS REQUIRED, THAT THE WORK IS COMPLETED.

☐☐

CORRECTIVE ACTIONS TAKEN:

DATE: _____

SIGNATURE: _____